


Ex9BL



RCBO
 Proudový chránič s nadpr. ochr.
 Prúdový chránič s nadpr. ochr.
 Wyłącznik nadprąd. z mod. różnicowoprąd.
 Interupator diferential/automate
 FI/LS-Schalter
 Interrupteur differential
 ДАВ
 Автоматичен прекъсвач с вградена ДТЗ
 Kombinovaná diferencijalna zaštitna sklopka

1

NOARK

Ex9BL

Mounting instructions
 Montážní návod
 Montážne inštrukcie
 Instrukcja montażu
 Istruzioni di assemblare
 Montageanweisung
 Instructions de montage
 Инструкция по монтажу
 Monteringsanvisning
 Istruzioni di montaggio
 Instrucciones de montaje
 Összeszerelési útmutató
 Uputstvo za montažu

Asennusohjeita
 Montage-instructies
 Instruções de montagem
 Navodila za montažo
 Οδηγίες Εγκατάστασης
 Инструкции за инсталиране
 Monteringsvejledningen
 Montažu upute
 Surinkimo instrukcijos
 Instalēšanas instrukcijas
 Скупштина упуство
 Paigaldusjuhendid


2

Ex9BL

Caution: Installation by electricians only
 Varování: Montáž pouze osobou s elektrotech. kvalifikací
 Varovanie: Montáž iba osobou s elektrotech. kvalifikáciou
 Uwaga: Montaż tylko przez uprawnionych instalatorów
 Atenție: Instalare numai de catre electricieni
 Vorsicht: Montagenur durch Elektrofachkräfte
 Attention: Montage uniquement par un électricien
 Осторожно: Монтаж только электрика
 Upozorenje: Montažu izvodi samo stručno lice


3

Ex9BL




4

Ex9BL




5

Ex9BL




6

Ex9BL




7

Ex9BL




8

Ex9BL




9

Ex9BL



10

Ex9BL



11

NOARK



Printed with environment-friendly paper
 Copyright Noark. All Rights Reserved
 Manufacturer: NOARK Electric (Shanghai) Co., Ltd.
 3857 Sixian Road, Songjiang District, Shanghai
 Importer: NOARK Electric Europe s.r.o. Sezemická
 2757/2 | 193 00 Praha 9 | Czech Republic
 www.noark-electric.eu
 Z9BL201710EU