




5 内部付属品の着脱 Fitting Internal Accessories 3-4 Pole




組み合せ Combination




6 本体取付要領 表面形 Breaker Mounting Procedure for FC




7 DINレールアダプタ (オプション) DIN Rail Adaptor (Optional) 3-4 Pole




9 本体取付要領 差込形 Breaker Mounting Procedure for PM




10 導体接続要領 裏面形・埋込形 Conductor Connection Procedure for RC/FP (Where Applicable)




11 可調整形の調整要領 Adjustment procedure for adjustable Thermal Magnetic Types




12 導体接続要領 表面形 Conductor Connection Procedure for FC



14 端子カバー取付要領 Terminal Cover Mounting Procedure



13 端子バリア取付要領 Interpole Barrier Mounting Procedure



15 ハンドルホルダ/ロック取付要領 Handle Holder / Lock Mounting Procedure

